

P/N 15063C INSTRUCTIONS


Replacing Blade Set for Slit & Ring Fiber Optic Cable Stripper

Replacing Ringer Assembly



1. Remove screw and washer (A)
2. Remove ringer blade
3. Replace with new ringer blade
4. Replace screw and washer
5. Set blade to required depth
6. Tighten screw

Replacing Slitter Assembly



1. Push pins out (A)
2. Lift out the slitter assembly
3. Replace with new slitter assembly
4. Re-insert the pins



Warning: Blades are extremely sharp.
Handle with care. Do not use on live circuits.